

LUBING

PLASTIC PAD CLEANING INSTRUCTIONS

The use of welded, highly resistant polymer sheets allows the Plastic Pad to be cleaned without difficulty and without damaging the Pads.



FIRST STEP:

Remove the dirty pad from the system

SECOND STEP:

Place it on a firm surface that allows dirty water to drain away

THIRD STEP:

Use a high-pressure cleaner with a maximum pressure of 1800 psi

Keep nozzle at a minimum distance of 6"



LUBING